



<p>2.0000</p>	<p>MISE EN GARDE: Vérifier l'article soigneusement avant chaque utilisation. Tirer sur la sucette de tous les côtés. Jeter et remplacer l'article au premier signe d'usure ou de dégradation. Ce produit n'est pas un jouet. Vérifier que les trous de ventilation de la sucette ne sont pas bloqués. Ne pas laisser la sucette exposée à la lumière directe du soleil ou près d'une source de chaleur. Par mesure d'hygiène et de sécurité, il est recommandé de changer la sucette après un ou deux mois d'utilisation. Ne pas tremper la sucette dans des substances sucrées ou des médicaments. Si la sucette vient à se coincer dans la bouche, la retirer délicatement, le plus doucement possible. Ne pas laisser l'enfant sans surveillance. Jeter tous les éléments d'emballage avant de donner l'article à l'enfant. Jeter et remplacer l'article au premier signe de dégradation ou si tout élément du fermoir à pince est usé ou mal attaché. Ne pas utiliser la pince pendant la sieste ou la nuit, ni si l'enfant joue ou rampe. Ne jamais utiliser dans</p>	<p>un lit de bébé, parc bébé ou lit d'appoint. Ne jamais rallonger la pince de sucette. Ne jamais attacher à des cordons, lacets, rubans ou des éléments lâches de vêtement car cela présente un risque de strangulation.</p> <p>PRODUCT AND DESIGN ARE TM & ©2013 MUNCHKIN, INC. MUNCHKIN, THE LATCH LOGO AND IT'S THE LITTLE THINGS ARE TRADEMARKS OR REGISTERED TRADEMARKS OF MUNCHKIN, INC. 7835 GLORIA AVE., VAN NUYS, CA 91406. MUNCHKIN BABY CANADA LTD., 50 PRECIDIO CT., UNIT A, BRAMPTON, ON L6S 6E3. PATENT: HTTP://WWW.MUNCHKIN.COM/PATENTS. MADE IN CHINA/FABRIQUÉ EN CHINE.</p> <p>munchkin It's the little things. munchkin.com 800.344.2229</p>	<p>munchkin LATCH Pacifier with Rattle Clip Instructions Mode d'emploi - Sucette avec fermoir à pince hochet</p> <p>0m+ Natural Shape Forme naturelle</p> <p>6m+ Orthodontic Orthodontique</p> <p>CCD-0119-001 REV1</p>
	<p>5.25</p>		
<p>2.0000</p>	<p>To Clean Pacifier: Before first use, place pacifier in boiling water for 5 minutes or steam sterilize, allow to cool, and squeeze out any trapped water. Wash and inspect before use. Hand wash in warm, soapy water. Top-rack dishwasher safe. Air-dry. Do not use disinfectant or microwave to clean.</p> <p>To Clean Rattle Clip: Hand wash fabric strap in warm, soapy water. Wipe plastic shield and clip with damp cloth. Do not bleach. Air-dry.</p> <p>To attach shield with clip to pacifier: Snap plastic shield into back of pacifier. Ensure shield is completely snapped in all the way around the pacifier.</p> <p>To remove, gently pop shield out by pressing down on pacifier rim with thumbs.</p> 	<p>WARNING: Inspect carefully before each use. Pull pacifier in all directions. Discard and replace at first sign of weakness or damage. This is not a toy. Ensure pacifier ventilation holes are not blocked. Do not leave pacifier in direct sunlight or near a source of heat. Replace the pacifier between one and two months of use, for safety and hygiene reasons. Do not apply sweet substances or medication on the pacifier. If the pacifier becomes lodged in the mouth, remove from the mouth with care, as gently as possible. Do not leave child unattended. Discard all packaging components before giving to the child. Discard and replace at first sign of weakness or if any part of the clip is worn or not securely attached. Do not use clip during nap or nighttime, while playing or crawling and never use in a crib, travel yard or bed. Never lengthen the pacifier clip. Never attach to cords, ribbons, laces, or loose parts of clothing as this may pose as a strangulation hazard.</p>	<p>Nettoyage de la sucette: Avant la première utilisation, plonger la sucette dans l'eau bouillante pendant 5 minutes ou stériliser à la vapeur, laisser refroidir et exprimer toute l'eau. Laver et vérifier l'article avant l'emploi. Laver à la main dans de l'eau chaude savonneuse. Lavable dans le panier supérieur du lave-vaisselle. Laisser sécher à l'air libre. Ne pas utiliser de désinfectant ni stériliser au microondes.</p> <p>Nettoyage de la pince hochet: Laver à la main l'attache en tissu dans de l'eau chaude savonneuse. Essuyer la pince et le fermoir plastique avec un chiffon humide. Ne pas utiliser de Javel. Laisser sécher à l'air libre.</p> <p>Fixation du fermoir à pince sur la sucette: Insérer le fermoir plastique au dos de la sucette. Vérifier que le fermoir est complètement inséré dans le bord de la collerette.</p> <p>Pour retirer, dégager le fermoir en appuyant sur le bord de la collerette avec les pouces.</p> 
	<p>3.5000</p>		